



C.I.Agent® Barrier Boom - It's so easy to install



1. No Special Equipment

All you need is rebar or wooden stakes, staple gun, hammer, shovel, rake, and C.I.Agent® Barrier Boom.
Optional Equipment: A small trench digger and 10 foot angle iron.



2. No Special Labor Skills

After trench has been dug to specified depth and width, place stakes or rebar inside trench every 10 feet.



3. Easy-To-Handle Material

Place the C.I.Agent® Barrier Boom beside the trench in lengths of specification and unroll.



4. Secure Barrier Boom

Stand the Barrier Boom up in the trench and staple to the stake. If using rebar, lean Barrier Boom against it. **REMEMBER:** Black side to face inside.



5. Protect Barrier Boom

Dump clean stone in the trench and around the Barrier Boom being careful not to crush the boom. A 10 foot angle iron can be used to deflect the stone during the fill process.



6. Continued Protection

Resting the angle iron on the stakes or rebar, pull the angle iron to the next support during filling. Remove angle iron when finished.



7. Dike the Boom with Stone

Dike the Barrier Boom with stone to the specified height.



8. Fast, Effective Protection

Secondary containment is complete and requires no maintenance.

All installations insured against environmental clean ups.

Critical Fuel Technology, Inc.